

How to fit a replacement net bag

350, 300, 250 and 200mm wide Net Frames

Start with the seam of the bag in the middle in front of you and for right handed people thread the brass ring into the bag collar. If there is a stitch end in the way inside it may require pushing.



Continue until the brass is threaded all the way round the bag up to the original hole. The brass will now be tight in the bag.



When you have the end of the brass left place a plastic tube over the end, push that into the bag and insert the other end of the ring into the plastic tube.





With the ring now in place it will be a firm fixture, Align the bag with the frame the correct way round. The narrow end towards the handle and the holes in the frame near the top. When fitted this allows the frame to protect the bag in both directions of sweep.



Place the P clips through the holes as shown in the photograph. Insert the bolts from the outside in, add the nut and tighten as much as possible. Take care to pull out the bag collar until it is smooth prior to tightening.

